



INSTALLATION INSTRUCTIONS PHONOLOOK ECOTWIN BAFFLE SUSPENSION



THE APPLICATOR IS RESPONSIBLE FOR THE CHOICE OF THE SCREW AND DOWELS.




THE FOLLOWING TABLE CHART SHOWS THE DISTANCES BETWEEN THE HOLES AND THE EDGE OF THE PANEL.

DIMENSIONI	N° CABLES	CABLE DISTANCE FROM THE EDGE	
		DISTANCE X	DISTANCE Y
300 mm x 1200 mm	2	50 mm	25 mm
300 mm x 1800 mm			
600 mm x 600 mm			
600 mm x 1200 mm			
600 mm x 1800 mm			
1200 mm x 1200 mm			



POINT
1

DRILLING




1. DRILL A HOLE IN THE POINTS INDICATED IN THE TABLE CHART.



POINT
2

CYLINDRICAL CLAMP FIXING




2. INSERT THE EXPANSION DOWEL.
3. FIX THE CYLINDRICAL CLAMP WITH THE SCREW.



POINT
3

CABLE CLAMP FIXING




4. INSERT THE CABLE INTO THE CABLE CLAMP AND INTO THE CYLINDRICAL CLAMP.
5. TIGHTEN THE CABLE CLAMP COMPLETELY.
6. TIGHTEN FIRMLY THE SAFETY NUT.



POINT
4

APPLICATION OF THE CABLE CLAMP TO THE PANEL




7. FIX THE CABLE CLAMP WITH THE GRUB SCREW IN THE PANEL
8. INSERT THE CABLE INTO THE CABLE CLAMP AND INTO THE CYLINDRICAL CLAMP, MAKE SURE IT COMES OUT OF THE SIDE HOLE.



POINT
5

PLACEMENT OF THE PANEL




9. SCREW THE CYLINDRICAL CLAMP COMPLETELY.
10. ADJUST THE CABLE LENGTH AS REPORTED IN THE PROJECT.
11. TIGHTEN THE SAFETY NUT.



POINT
6

FINAL CHECK



12. VERIFY THE CLOSURE OF THE SAFETY NUT AND OF THE HOOK.
13. VERIFY THE CORRECT PLACEMENT OF THE PANEL.